








Montageanleitung Mounting Instruction Instructions de montage Istruzioni di Montaggio










pro(arc
PowerSlide[®]







"H"	"L"					"X"									
	555	600	640	685	725	224	256	288	320	352	384	416	448	480	
600 - 632	X					X	X	X							
633 - 664	X					X	X	X	X						
665 - 696		X				X	X	X	X	X					
697 - 728			X			X	X	X	X	X	X				
729 - 760				X		X	X	X	X	X	X	X			
761 - 792				X		X	X	X	X	X	X	X	X		
793 - 824					X	X	X	X	X	X	X	X	X	X	



2x



1x




4x




D4x35

8x








D4x30

4x



D4x20





"H"	"L"					"X"								
	555	600	640	685	725	224	256	288	320	352	384	416	448	480
600 - 632	X					X	X	X						
633 - 664	X					X	X	X	X					
665 - 696		X				X	X	X	X	X				
697 - 728			X			X	X	X	X	X	X			
729 - 760				X		X	X	X	X	X	X	X		
761 - 792				X		X	X	X	X	X	X	X	X	
793 - 824					X	X	X	X	X	X	X	X	X	X

